

Every inspection, *reviewed* in ITpipes CoreVision.

The simple way for any third party without ITpipes CoreVision, from contractors to engineering firms and partner agencies, to upload mainline, manhole, and lateral inspections straight into your CoreVision platform.

ITpipes Connect FEATURES & BENEFITS

Let Any Third Party Deliver Inspections Straight Into CoreVision

When someone outside your organization captures and manages inspections for you, whether a contractor, engineering firm, or partner agency, getting that work into your system has meant manual rekeying and lost time. **ITpipes Connect closes the gap.** It is a lightweight Windows utility that lets any third party who does not have ITpipes CoreVision upload a completed NASSCO v6 or v7 exchange database, directly into your CoreVision platform. The inspections populate automatically into a project in CoreVision, where your team can review, code, and Q/A them.

KEY BENEFITS

01

Open to any third party

Anyone without ITpipes CoreVision, from contractors to engineering firms and partner agencies, can deliver completed inspections into your account, with no ITpipes seat and no manual rekeying on their end.

02

Every asset type you inspect

Bring in mainline, manhole, and lateral inspections, as long as the matching modules are configured in your CoreVision account.

03

Lands ready to review in CoreVision

Uploaded inspections populate automatically into a project in your CoreVision account, ready for your team to view, code, and Q/A.

04

Standards-based and simple

Senders provide a standard NASSCO exchange database using NASSCO v6 or v7, so inspection data comes in clean and consistent.

AT A GLANCE

- ✓ One-way upload from a third party into your CoreVision account
- ✓ Simply upload a NASSCO **v6 or v7** exchange database
- ✓ Supports all configured CoreVision asset types: **mainline, manhole, and lateral**
- ✓ Automatically creates assets and inspections in a CoreVision project
- ✓ **No ITpipes CoreVision license** required for the third party
- ✓ Web based; works with on-prem or cloud-hosted CoreVision
- ✓ Requires login credentials provided by the CoreVision client

HOW IT WORKS

STEP 1

Share access

Provide the third party with the ITpipes Connect installer and login credentials for your CoreVision account.

STEP 2

They log in

The third party installs Connect and signs in using the credentials and CoreVision URL you provide.

STEP 3

Upload the database

They select the completed NASSCO exchange database and upload it.

STEP 4

It lands in CoreVision

Connect creates the assets and inspections automatically and populates them into a project in your CoreVision platform, ready to review, code, and Q/A.

BRING EVERY INSPECTION INTO COREVISION

Let any contractor or partner deliver inspections straight into your platform. Talk to us about turning on Connect.

Speak with an Expert →