Contractor Sync

FOR CONTRACTORS

Take the assignment. Deliver *without* the handoff.

Contractor Sync links your CoreVision account directly to your client's, so their work orders land in your system and your finished inspections go back to them without an export, a drive, or a file transfer.

Contracted CCTV work comes with administrative overhead that has nothing to do with inspection. Scopes arrive as lists to retype, deliverables go out as exported files on drives or FTP, and then you wait to hear whether anything came back rejected. **Contractor Sync removes that overhead.** Your client's CoreVision account and yours are connected project to project, so you download their work orders, reassign them to the right truck, run the inspections, and submit them for evaluation in one action. Their accept or reject decision returns to you in real time, with a reason attached whenever something needs correcting.

WHY IT MATTERS FOR YOUR BUSINESS

01
Scopes arrive ready to run
Download the client's work orders straight into your account with the assets already identified, then reassign them to the right truck. Nothing gets retyped from a list.

02
No deliverable packaging
Submit completed inspections for evaluation from the platform your crews already work in. No exports to build, no drives to ship, no FTP transfers to chase.

03
Rework you can act on
When a client rejects an inspection they have to give a reason, so you know exactly what to correct. Fix it and resubmit in the same tool instead of trading emails and rebuilding a package.

04
Faster acceptance, faster billing
Work moves from submitted to accepted inside the platform, so approvals are not waiting on a delivery to arrive and get imported. Accepted work is documented the moment the client signs off.

05
A record of what you delivered
Every submission, acceptance, and rejection reason is logged in your own account. If scope or quality is ever questioned, the history is there without digging through email.

06
Easier to work with, easier to rehire
Clients see live status and clean data without asking for an update. Running contracts this way makes you the low friction option when the next one goes out.

AT A GLANCE

- ✓ Connects **your CoreVision account to your client's**, project to project
- ✓ Download **client work orders** directly into your account
- ✓ **Reassign work orders** to the right truck or crew
- ✓ **Submit inspections for evaluation** in a single action
- ✓ Accept or reject result returns as **Work Status in real time**
- ✓ Rejections carry a **reason**; resubmit without repackaging
- ✓ Smart Tab tracking by **Work Status** and **WO Status**
- ✓ Enabled per project on both sides; no new software to install

ONE CONNECTED LOOP

YOUR SIDE

- **Download the client's work orders** into your own account
- **Reassign to the truck** or crew running the work
- Run the inspections and **submit them for evaluation**
- **Resubmit corrections** without repackaging a deliverable

CLIENT SIDE

- **Scopes the work** from their map or asset list and assigns it
- **Accepts or rejects** each submitted inspection
- Supplies a **reason on any rejection** so you can correct it
- Sees **live Work Status** without asking you for an update

DELIVER WORK WITHOUT THE HANDOFF

Connect your account to your client's and run contracted work end to end in one platform. Ask us about turning on Contractor Sync.

Speak with an Expert →